## **CAUTION! READ BEFORE USE!**

## **IMPORTANT**

**Caution:** Turning or lifting a tank for insertion or removal without applying slight downward pressure prior to locking or removal can damage the tank or the system.

**Tank insertion:** Do not drop tank into the tank well. Carefully apply slight downward pressure on the tank and turn **clockwise** 1/4 of a turn into the locking position.

**Tank removal:** Carefully apply slight downward pressure on the tank and turn **counterclockwise** ¼ of a turn to unlock before lifting to remove.

Please read the manual and quick start guide before use.

Scan the following QR code to watch a short instructional video.



